

IMPORTANT DOCUMENT

Fitting Instructions for Adtech FEP Boots



1. Slide the boot all the way over the lamp.



**2. Leave a gap between the tip of the lamp and the welded end of the boot.
(We recommend 10mm between inside of weld and lamp tip)**



**3. When shrinking always start at the glass section .
(just before where the boot is starting to flare out slightly)**



4. Shrink material fully and work towards the end of the plastic cap.



4. Make sure the material has shrunk fully.



5. Trim the material from the end of the lamp.